HOW TO CREATE A PELEMAN PRINT COVER ON THE EPSON P900

Register your Peleman user account

STEP 1 - Go to https://peleman.com, Register to create an account or login into your existing account.

STEP 2 - Go to MY ACCOUNT > LICENSES > Enter the license key: PIC1-JMEU-K7KW-C4EX

STEP 3 - After activation this license is linked to your account, and you can proceed to the editor.

Create your own Print Cover



Dashboard Printcovers

New


Flexcover

A4 P-40-4 Fold A4 P-40-2 Fold A4 P-40

Recent Projects

STEP1 - Click on "Create Print Cover".

STEP 2 - Choose the desired format.



STEP 3 - Upload your photos or logo's



STEP 4 - Use the Peleman Image Editor to create your design.




STEP 5 - The Peleman Image Editor will generate a printable PDF File.



STEP 6 - Open your generated PDF File




Printer Settings - Example on Epson P900



> Select the correct printer, in our example
Epson P900
> Select 'Actual Size'
> Select 'Landscape'

> Select 'Properties'



) 'Media Settings' > 'Media type' > 'Matte


Paper' > 'Epson Photo Quality Ink Jet'

) 'Media Settings' > 'Mode' > 'Epson-standard


(sRGB)'

) 'Paper Settings' > 'Source' > 'Front - Poster Board'

Select 'User-defined...'



- Fill in the right measurements that are indicated
- Give your paperformat a correct name. (For example: PrintCover A4 Portrait)
- > Press 'Save'
- > Press 'OK'



> Press 'Print'



